

## Bullfinch Shower Point No. 6088 Installation Instructions.

Caution: This product should be installed by a suitably qualified competent person into pressurised water systems. For non pressurised systems a separate pump switch is required.

1. Select an appropriate site to fit your Shower Point that has clear access to the internal hot and cold supply.
2. Ensure that when selecting a suitable site any water from the shower head cannot come into contact with any external electrical connection, and that when using the shower any electrical connections cannot be touched.
3. Ensure that there are no electrical cables, water or gas pipes that could be damaged when cutting the holes. Also check for bulkhead brackets that could make fitting of the Shower Point difficult.
4. Once a suitable site has been selected mark the position for the centre hole.
5. Using a 60 to 65 mm diameter hole cutter, carefully cut through the panel.
6. Offer up the Shower Point to the hole and mark the four mounting holes through the unit.
7. Use an appropriately sized drill for the screws to be used and drill the four fixing holes.
8. Mount the Shower Point to the wall using suitable screws.
9. If gaps are detected around the edges of the Shower Point use a Silicon sealant to add extra sealing.
10. The connection to the water supply is by 15 mm quick fit "Whale" fittings. Whale fittings are only suitable for plastic or flexible pipe. If using copper use appropriate fittings.
11. Ensure that the connections are made to the correct feeds on the Shower Point (Inlet feeds marked red (hot) and blue (cold)).
12. Check all joints and correct any leaks before use.

